Samsung Rant Back Cover Replacement

Remove the back cover from the cell phone.

Written By: Denise Cooper



INTRODUCTION

Remove the back cover from the cell phone to expose the battery and internal parts of the phone.

Step 1 — Back Cover



- Turn phone over in the palm of your hand, with the screen facing down.
- While grasping the bottom part of the phone with one hand, use your thumb to push the release button at the end of the phone.
- This will release the back plate latch; then lift the back plate up and out toward the other end of the phone.
- You should now be able to lift the plate completely off the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 12:23:26 AM.